


# Residential Sliding Gate Motor Installation



- A** KEYSWITCH
- B** OBSTACLE SENSORS
- C** WARNING LIGHT/ANTENNA
- D** OPTIONAL SENSOR POST
- E** GATE STOP
- F** GATE TRACK
- G** LIMITER SWITCH - OPEN
- H** GEAR RACK
- I** GATE MOTOR
- J** LIMITER SWITCH - CLOSED



## Easy to install...

- 1 Mount the motor on a concrete base using the mounting plate provided.
- 2 Mount the keyswitch
- 3 Mount the obstacle sensors
- 4 Mount the warning light/antenna
- 5 Connect the colour coded wires.
- 6 Screw the rack to the back of the gate.
- 7 Fit the limiter switches to the rack.

The unit is provided with a 240volt plug for testing, just plug in with an extension cord. Permanent connection should be done by a licenced electrician.